


How to make account setting_Stalker

① When using IPTV Interface

1) Press the red button by the remote control



2) Then, press the OK button (by the remote control) to activate keyboard



3) To use special character such as ‘:’, ‘-’ press the red button (CAP)



* Don't Forget to put your Stalker Mac Address in server


How to make account setting_Stalker

② When using Web Interface

1) Go to the [http://\(your receiver IP address\):8080](http://(your receiver IP address):8080) via internet











2) Then, you will see the Authentication box. Fill the blank.



3) Press the 'Stalker' menu on the top.
Then, press the 'Pencil Icon' 

Protocol Password
Stalker Xstream Code M3U/User IPTV

You can register maximum of 4 stalker accounts

Stalker Portal	Portal URL	User Name	Password	Action
Portal1	http://IP-address or dyndns			 
Portal2	http://IP-address or dyndns			 
Portal3	http://IP-address or dyndns			 
Portal4	http://IP-address or dyndns			 

4) Write down Portal URL, User name and Password

Edit Portal1 Account

Stalker account settings	
Portal URL:	<input type="text" value="http://IP-address or dyndns"/>
User Name (by option):	<input type="text" value="<User name>"/>
Password (by option):	<input type="text" value="<Password>"/>
<input type="button" value="Save"/>	

5) Save and Use the Stalker menu right now!

* Don't Forget to put your Stalker Mac Address in server