

---


Produced in ChRL for:  
DMTrade Mikołaj Tomaszewski  
Wiśniowa 36;  
64-000 Kościan, Poland  
NIP: PL 6981681757  
sklep@dmtrade.pl  
Tel.:  
+48 661082052  
+48 785082052

---

## Video Distributor Spacetronik SPD-VD04

---

### USER MANUAL




---

Please read this manual carefully before using the product .

Description: Video distributor with 4 branches with the function of isolation and protection.

- Can be used as 4 inputs (Outdoor stations) controller or 4 outputs (Indoor monitor) controller;
- Separate isolation protection without affecting another devices on the bus system;
- Short-circuit indication for convenient maintenance;
- Periodic self-detection mechanism for recovery.

## 1. Parts and Functions



**IN-USE:** Status indicator, it will light up when receives signal.

**POWER:** Working indicator, it will light up when plugs in power supply.

**Impedance Switch:** Video match switch, the last video distributor at the end of the bus should set ON to match the video impedance, the power indicator will turn to orange after setting.

**Bus:** Input port, bus connection port.


**A, B, C, D:** Output port, connect to indoor monitors or door stations.

### Note:

- **Operation mode:** Protection mode will be activated once its connected devices are short circuited, and power supply for ABCD outputs will be turn off, the flashing in-use indicator shows the distributor is in the protection mode.
- **Self-detection:** System will auto check whether the short circuit is fixed or not, then recover the power supply, and in-user indication will be turn off;

- **Detection period:** Self-detection will be happened regularly according rules, and in-use indicator will flash rapidly three times when check happens;  
1st detection will be happened in 10 seconds after short circuit;  
2nd detection will be happened in 60 seconds after 1st detection;  
3rd detection will be happened in 5 minutes after 2nd detection;  
4th detection will be happened in 10 minutes after 3rd detection;  
5th hereafter detection will be happened every 30 minutes.

## 2. Unit Mounting



## 3. Wiring

### Multi-door station

